


## Preparing For Installation

Before installing your device, please record your device serial number. You will need this information at a later time to verify your installation.

1. Verify that we support your vehicle by carefully reading the device release notes at [goo.gl/fZURff](http://goo.gl/fZURff) or from the vehicle specific installation notes at [goo.gl/MCIXt0](http://goo.gl/MCIXt0). If you have any questions or concerns, please consult your Authorized Reseller.
2. Ensure no dash warning lights are on in the vehicle while it is running, and all other functions such as headlamps and flashers etc. are working prior to installing the device.

## Installation Instructions

 Read important related safety information and limitations of use following these installation instructions. Read and follow all instructions and warnings to prevent serious injury and/or vehicle damage.

**WARNING!** Prior to GO installation, read and follow important safety information including limitations of use located following these installation instructions. Always read and follow all safety information to prevent loss of vehicle control and serious injury.


**WARNING!** Some installations are not straightforward and must be completed by an Authorized Geotab Installer to ensure a secure installation. An unsecure device installation can cause poor electric and/or data connection that can lead to short circuits and fires or cause malfunctions of vehicle controls that can result in serious personal injury or significant damage to your vehicle. Some examples requiring professional installation from an Authorized Geotab Installer are:

- The OBD port location is such that the device protrudes and interferes with entering or exiting the vehicle, or located where it could be inadvertently kicked or bumped during vehicle operation
- The device isn't fully secured and so may come loose with vibrations or accidental contact
- An electrical harness or additional wiring is required
- Vehicle mounting modifications are required to secure the device, i.e. removing of panels; deformed/damaged OBD connector; or physical damage to the electrical wiring
- The device does not beep six times and power on when first installed
- The installer questions their ability to complete a secure installation according to these instructions


**WARNING!** Do not attempt to install, reconfigure, or remove any product from a vehicle while the vehicle is in motion or otherwise in operation. All installation, configuration, or removal must be done only in stationary vehicles which are securely parked. Attempting to service devices while the vehicle is in motion could result in malfunctions or accidents, leading to death or serious personal injury.

- 1 Locate the vehicle's engine diagnostic port, typically found in the driver's area at or below knee level.


**Note:** Heavy-duty vehicles use a different connector system. Contact your Authorized Geotab Reseller for heavy-duty connector applications or for extension harnesses should it be necessary to place your device away from the engine diagnostic port.




- 2 Align the receiver end of the device with the engine diagnostic port and simply push in place, ensuring that the device is well connected to the diagnostic port. You will hear 6 quick beeps and all three lights on the device will flash briefly.



3 With the vehicle parked outdoors to locate satellites and vent exhaust fumes, start the vehicle and allow it to run for approximately 3 minutes. During this period you will notice the Red LED power on and glow on the face of the device. Shortly afterwards the Green and Blue LEDs will light up when the device connects with the cellular and GPS networks. This initial startup may take several minutes to complete.



4 Once all three LED lights have lit up, secure your device using the supplied cable tie.



5 When performing under-dash installations with an extension harness, make sure the antenna side is always pointing upwards towards the sky for faster GPS latch times. The GPS antenna in a **GO8** is located on the bottom side of the device.

6 Please verify that the device is communicating correctly. Using a PC or smart phone, navigate to [installmygps.com](http://installmygps.com).

Fill in your name, company, and the Geotab GO device serial number (found at the bottom of the device) and click on **Log Install**.

7 You will now see a screen that displays the current status of the device. If the device is communicating correctly, you will see **GREEN** lettering with the last valid GPS record. If the text appears in **RED**, the device is unable to communicate and you must verify the installation.

**Installer Name:**

**Installer Company:**

**Device Serial No:**

**Odometer:**

**Asset Number:**

**WARNING!** All in-vehicle devices and related cabling must be securely fastened and kept clear of all vehicle controls, including gas, brake and clutch pedals. This requires the use of a cable tie when securing the device or any extension harness to the OBD connector, securing both sides of the harness. If you do not use a cable tie, vibration in the vehicle can lead to a loose connection which could indirectly cause the vehicle's engine computer to fail, loss of vehicle control and cause serious injury. Inspect devices and cabling regularly to ensure all devices and cables remain securely attached.

**WARNING!** If at any point after an in-vehicle device is installed a warning lights up on the vehicle dash or the vehicle stalls or has a marked drop in performance, shut off the engine, remove the device, and contact your reseller. Continuing to operate a vehicle with these symptoms can cause loss of vehicle control, and serious injury.